


Setup Guide

5-037-329-11(1)



GB	Setup Guide	RU	Руководство по установке
CS	設定指南	TH	คู่มือการติดตั้ง
CT	安裝指南	ID	Panduan Penyetelan
VN	Hướng dẫn cài đặt	AR	دليل الإعداد
FR	Guide d'installation	PR	راهنمای نصب



1

SN

AR

CA

CB

FB

IM

R03

LR03

M5L12

M4L11

1.5 N·m/1,5 N·m

{15 kgf·cm}

2

1

SB

*1

2

3

A

1

SN

SB

2

M4L11

x 4

3

B

1

AR

SB

2

M5L12

SN

3

M4L11

x 4

4

4

✓

✗

✗

✗

5

A

1

2

B

1

2

6

1

2

3

M5L12




x 4

*1 Only for limited region/country/model. / 仅针对有限的地区/国家/型号。 / 僅限用於有限區域/國家/型號。 / Chỉ dành cho một số khu vực/quốc gia/model. / Uniquement pour certaines régions, certains pays ou certains modèles. / Только для определенных регионов/стран/моделей. / สำหรับบางภูมิภาค/

ประเทศไทย/พื้นที่อื่น / Hanya untuk kawasan/negara/model tertentu. / لمناطق/بلدان/موديلات محددة فقط. / فقط برای بعضی مناطق/کشورها/مدلها.

© 2022 Sony Corporation Printed in Malaysia

7




*2 < 14 (mm) *3 < 7 (mm) *4 < 21 (mm) *5 3.5/3.5 (mm) 12 3 4

1: L / 左 / G / Левый
2: Video / 视频 / 視訊 / Vidéo / Видео / วิดีโอ / الفيديو
3: GND / Terre
4: R / 右 / D / Правый


(mm) / (毫米) / (MM) / (ملليمتر) / (میلی متر)

8




*6 Wood screw / 木螺丝 / 木螺絲 / Vít gỗ / Vis à bois / Шупун / สกรูไม้ / Sekrup kayu / برغي الخشب / پیچ چوبی


9




10




11




12



13



14



15

