

SodaStream

your home soda factory

- C100 Cool
- A200 Jet/Stream
- DS5001 Design

SodaStream
Distributed by
Soda-Club USA, Inc.
PO Box 4386
Cherry Hill, NJ 08034-0863
Toll-Free: 1-800-763-2258
www.sodastream.com

USER MANUAL	BRUGERMANUAL	NAUDOJIMO INSTRUKCIJA
BRUKERMANUAL	ÄYTTÖOHJEET	LIETOŠANAS INSTRUKCIJA
BRUKSANVISING	KASUTUSUHEEND	ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

SodaStream

your home soda factory




UK: Soda-Club Worldwide Trading Company 7 The Office Village Cynriel Park, Forder Way Peterborough PE7 8GX Tel: 0800 085 8373 www.sodastream.co.uk	AUSTRALIA: Soda-Club Australia Pty Limited 5 Keysborough Close Keysborough, Victoria 3173 Tel: 1 800 005 199 www.sodastream.com.au	SWEDEN / SVERIGE / RUOTS: Soda-Club Scandinavia AB Osternämsvägen 87 C 114 59 Stockholm Tel: +46-(0)771-33 34 00 info@sodastream.se www.sodastream.se
SOUTH AFRICA: Soda-Club (SA) (PTY) Ltd. Route 21 Corporate Park 48 Sovereign Drive Ilere ext 30, Centurion Tel: 0800-00-22-91 www.sodastream.co.za	BALTIC STATES: Empire Baltics, Pulkveža Brieža 41-209 LV-1045, Rīga, Latvia Tel: +371-673 21 205 www.sodastream.lv www.sodastream.it	NORWAY / NORGE: Soda-Club Scandinavia AB Tel: +47 800 30 095 info@sodastream.no www.sodastream.no
NEW ZEALAND: SodaStream (New Zealand) Ltd. PO Box 34521 Birkenhead Auckland Freecall: 0800 763 278 www.sodastream.co.nz	Esti: OÜ Mullmeister, phone +372 6661156 www.sodastream.ee	FINLAND: Maaniliiga, ETACAP OY Vanha Porvontie 229 01380 Vanhaa Tel: +358 (0)9 4730 4421 www.sodastream.fi

www.sodastream.com



GETTING STARTED

Säta igång
Start med
Sådan kommer du i gang
Toimi näin
Austamine
Kaip praadeti
Ar ko säki
Поправок паботы



Dear customer
Thank you for choosing to buy one of our quality drinkmakers. For fullest satisfaction please read the user instructions carefully. We are always happy to answer your questions, to contact your nearest Soda-Club SodaStream office please visit www.sodaclub.com
PLEASE NOTE: Before exchanging an empty cylinder for a full one, please make sure to ask for a Soda-Club SodaStream CO₂ cylinder that fits your drinkmaker model. Do not try to fit a cylinder other than the type(s) suitable for your drinkmaker model, as indicated on your drinkmaker's package.

Getting started:

1. Press the fill lever and remove the bottle from the drinkmaker (A1, A2).
2. Remove the back cover (B1, B2).
3. Remove the valve seal and cap from the cylinder valve. Insert the cylinder into the drinkmaker (C1, C2, C3) and screw it tightly into the cylinder holder (do not use any tools). Replace the back cover (D1, D2).
4. Fill the carbonating bottle with water to the fill line and chill.
5. Press the fill lever and screw the bottle into the drinkmaker (E1, E2).
6. Press the carbonating button in short presses until you hear the buzz (release the button between presses). 3 buzzes will produce a standard fizz, additional presses will produce a stronger fizz (F).
7. Press the fill lever and unscrew the carbonating bottle to remove from the drinkmaker (G1, G2).

IMPORTANT:

Carbonate only when the drinkmaker is in the upright position. Carbonate only drinking water, without any additives. Never carbonate an empty bottle.

YOU CAN CHOOSE FROM A VARIETY OF FLAVOURS

A wide range of flavours is available from Soda-Club SodaStream. In bottles or in single servings. Please read mixing instructions on concentrate packaging labels before making drinks.
Store flavours in a cool dark place.

REPLACING A SODA-CLUB/SODASTREAM CYLINDER:

1. Remove the carbonating bottle from the drinkmaker.
2. Remove the rear cover.
3. Unscrew the empty cylinder and remove from the drinkmaker.
4. Repeat step 3 of "Getting Started" above.

BEFORE CALLING FOR SERVICE

1. If your drinkmaker does not carbonate:
 - If your cylinder is empty, exchange it. The weight of the full or empty cylinder is printed either on the cylinder or on its valve.
 - Check that the carbonating bottle has been filled up to the fill line.
 - Ensure that the drinkmaker is always in the upright position.
2. If your drinkmaker continues to release gas after the carbonating button has been released:
 - DO NOT REMOVE THE CYLINDER OR THE BOTTLE. LEAVE THE DRINKSMAKER IN THE UPRIGHT POSITION AND DO NOT TOUCH THE DRINKSMAKER until escaping gas is no longer heard.
 - When gas is no longer being released, tilt the carbonating bottle and remove. Unscrew the cylinder and return it to your supplier.
3. If a low hissing noise is heard from the drinkmaker during carbonation:
 - Exchange the cylinder for a full one. Attention: the cylinder may be very cold.
 - Discard the carbonating bottle that was filled into the drinkmaker and replace it with a new one.
 - In case of damage stop using the drinkmaker and contact the Customer Care Team in your country.
4. If a slight hissing of gas may be heard when the drinkmaker is under pressure. This is quite normal and the noise will stop after carbonation when the bottle is tilted and the pressure is released.
4. If, when fitting a new cylinder, gas leaks after you have screwed the cylinder to the drinkmaker:
 - There may be a pressure leak between the cylinder holder and the cylinder valve.
 - Screw the cylinder tighter into its holder. If this does not help, remove the cylinder immediately and check if the rubber seal (a small black rubber ring) is in place. If it is missing or has slipped out of place, replace it. You can obtain spare seals from your local Customer Care Team.
5. If water over-flows from the carbonating bottle during carbonation:
 - Have you over-filled the carbonating bottle? Check the fill line and empty excess water if necessary. Are you pressing the carbonating button too long? Use short, firm presses only.

LOOKING AFTER YOUR SYSTEM

CARING FOR YOUR DRINKSMAKER

Wipe your drinkmaker with a soft damp cloth. Do not wash in a dishwasher. Do not place or store the drinkmaker close to a heat source. Keep dry the drip tray at the bottom of the drinkmaker. The drip tray can be removed for cleaning if desired.

CARING FOR YOUR SODA-CLUB/SODA-STREAM CARBONATING BOTTLES

The carbonating bottles designed for your drinkmaker have a screw style fitting.

Please ensure that all extra bottles purchased have a screw type fitting. Do not use any carbonating bottles which are not approved by Soda-Club SodaStream for use in your drinkmaker model, including, inter alia, bottles made by other manufacturers or bottles made of glass.

After every use, rinse your carbonating bottle with lukewarm tap water with or without soap. For easy cleaning you may remove the base cup of the bottle by pulling the base downwards. Replace the base cup by pressing it onto the bottle from the bottom. Always refill immediately with fresh cold drinking water and then place in the refrigerator for pre-chilled drinks. Do not allow materials such as ammonia, alcohol or benzene based substances to come into contact with the bottle, as these may distort it.

Soda-Club SodaStream Carbonating Bottles can be damaged by extremes of heat or cold (above 50°C or below 1°C) - never wash your bottle or its cap in the dishwasher, do not leave close to a direct heat source (oven or radiator) or in the car and do not place in the freezer.

Certain types of Soda-Club SodaStream carbonating bottles may be placed in the dishwasher (once a week - up to 70°C or Eco cycle) for cleaning. Look for the "dishwasher safe" indication on the bottle to know whether the bottle may or may not be placed in the dishwasher.

Check bottle caps occasionally for wear or cracks.

WARNING:

Every SodaStream Carbonating Bottle carries an expiry date - DO NOT use a bottle once this date has passed.

Soda-Club SodaStream Carbonating Bottles are subjected to stringent quality tests and with normal usage should reach their expiry date with ease. If, however, you notice that your bottle has become worn, scratched, discoloured, lost its transparency or shape or was damaged, DO NOT use it in your drinkmaker any longer. Please discard the bottle immediately and replace it with a new one.

SODA-CLUB/SODA-STREAM CYLINDERS

The Soda-Club SodaStream Cylinders are not for sale. These cylinders are the property of Soda-Club (CO₂) Ltd. or its affiliate as indicated on the cylinder and the User Certificate attached to the cylinder. The Soda-Club SodaStream Cylinder is transferred to you temporarily, subject to the terms of the Certificate, only for the specific purpose of carbonating water by means of a suitable drinkmaker.

When the cylinder is empty, exchange it for a full Soda-Club SodaStream Cylinder at an authorised Soda-Club SodaStream Retailer for the price of the gas refill only.

Warning: Store cylinders in a cool place. Exposure to heat will cause the pressure in the cylinder to rise. As a safety precaution, the cylinder will expel the CO₂ if the pressure inside the cylinder becomes too high. If this should happen, do not touch the cylinder, simply leave it until all the gas has escaped. In such case, quick release of CO₂ causes the cylinder to become extremely cold. Do not touch the cylinder until it has warmed to room temperature.

NEVER TRANSPORT THE DRINKSMAKER WITH THE CYLINDER IN PLACE.
DO NOT TAMPER WITH THE CYLINDER.

WARRANTY

Great care has been taken to ensure that your drinkmaker is delivered to you in perfect condition.

However, if a fault should occur during a 24 months period following the date of purchase (please keep the receipt) due to faulty workmanship or inferior raw materials, we will either repair or replace (at our discretion) your drinkmaker free of charge.

Even if the fault has occurred due to misuse, we remain at our service but of course we would then request payment for the repair, which can be arranged through an authorised Soda-Club SodaStream Retailer or your customer care team. The efficient repair or service of the drinkmaker cannot be guaranteed to be carried out by any other party, and therefore, for the warranty to retain its validity, please arrange such repair or service through an authorised Retailer or customer care team.

If you have any questions, please call our Customer Care Team.

Soda-Club SodaStream carbonating bottles

Your drinkmaker has been designed to operate with a suitable Soda-Club SodaStream Carbonating Bottle (screw style fitting). It is not guaranteed to operate efficiently with any other bottle, and therefore for the warranty to retain its validity please use only original Soda-Club SodaStream Carbonating Bottles in your drinkmaker.

Soda-Club SodaStream cylinders

Your drinkmaker has been designed to operate with a suitable Soda-Club SodaStream Cylinder, as explained in the instructions in this manual. It is not guaranteed to operate efficiently with other cylinders, and therefore for the warranty to retain its validity please use only a suitable Soda-Club SodaStream Cylinder filled by an authorised Soda-Club SodaStream filling station, available from authorised Soda-Club SodaStream Retailers.

All Soda-Club SodaStream products are subject to continuous development and specifications may change without notice.

MACHINE RATING

Maximum working pressure: 10 Bar / 145 Psi. Maximum allowed operating temperature: 40°C/104°F. Bottle capacity at fill line will be in the range of 400 ml - 1.0 liter (varies by machine pack, may differ from images shown). Brimful bottle capacity will be in the range of 480 ml - 1.1 liter