



*Thinking of you*  
**Electrolux**

EDV5552

**RRP AUS \$639.00**

The 5.5kg clothes dryer comes with Sensor Dry to gently dry your garments for an exceptional result. Other features include ideal temperature settings, Fast 40 program, reverse tumbling action and anti-crease option.



# Product Details

## Features

<p><b>Sensor Dry</b> Sensor Dry cares for your clothes. 3 settings dry your clothes just right without overdrying.</p>	<p><b>Efficient Reverse Tumbling Action</b> The tumble action alternates from clockwise to anti-clockwise. This reduces clothes tangling and bunching, so they dry evenly and quicker.</p>	<p><b>Ideal temperature settings</b></p>	<p><b>Clean Filter Indicator</b> A reminder to clean the filter, keeping your dryer running in optimal condition, saving time and energy.</p>
<p><b>Durable stainless steel drum</b></p>	<p><b>Wall mount option with reversible control panel decal</b></p>	<p><b>Child safety device on door</b></p>	<p><b>Delay start option</b></p>

# Product Details

## Benefits

### Sensor Dry

Sensor Dry gently and precisely dries your garments for exceptional results. This easy-to-use program will also save you precious time and energy.

### Save time with the Fast 40 program

Dry your smaller loads within 40 minutes, for those times you just need to get things done quickly.

### Ideal temperature settings to suit different loads

With four settings, even your most precious items are in safe hands. Choose from the airing setting for uncomplicated aeration, low heat setting for your delicates, normal setting for regular loads, or use the boost setting for heavier loads.

### Efficient Reverse Tumbling Action

The tumble action alternates clockwise to anti-clockwise, reducing clothes tangling and bunching, so they dry evenly and quicker.

# Specifications

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Dryer Type	Exhaust venting front/rear
Capacity (Kg)	5.5
Wall mount option	supplied with unit

## ENERGY

Energy Star Rating	2
Energy consumption (KWhr/yr)	247

## BUTTON FUNCTIONS

Reminder/ Indicators	clean lint filter reminder,child safety lock door,end of cycle,delicate,buzzer,progress indicator,time dry,anti-crease phase duration
Functions	power/on/off,start /pause,airing,auto sensing,clean filter reminder,child lock,buzzer,delay start,anti crease,auto cool down,reverse tumbling drum action

## DIMENSIONS

Total height (mm)	795
Total width (mm)	600
Total depth (mm)	600

## CONTROLS

Type of controls	electronic push button
Options available	delicates setting,heat settings,delay start,auto sensing,Reversible control panel,safety thermostat heater,safety remote element,buzzer,anti-crease
Type of display	LED
Fabric type selection	delicate,normal

## DRYING PROGRAMS

Drying Programs	auto sensing,delicate,refresh,timed programs,extra dry,iron dry
Degree of dryness	extra,normal,iron dry
Venting	optional rear venting,directional front vent grille

## DRUM

Spin tub material	stainless steel
-------------------	-----------------

## DOOR

Type	See through door
Dryer Door colour	white
Door diameter	424
Door angle opening	168
Door safety	door safety switch

## CABINET

Cabinet Colour	white
Cabinet material	painted galvanized steel

## TECHNICAL

Service cord length	180
Dryer Lint filter position	front pocket
Buzzer	end of cycle
Dryer Element watts	2100
Dryer Safety thermostat heater	Yes

## SHIPPING

Shipping Volume (m3)	0.319
Shipping Weight (Kg)	28.5
Pack Dimensions Height (mm)	830
Pack Dimension Width (mm)	630
Pack Dimension Depth (mm)	610

## STUFFING QUANTITIES

40ft HC	171
---------	-----

# Terms and Conditions

## IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

## PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

## WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640  
fax: 1800 350 067  
email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)  
web: [www.electrolux.com.au](http://www.electrolux.com.au)

### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230  
fax: 09 573 2221  
email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)  
web: [www.electrolux.co.nz](http://www.electrolux.co.nz)