

SWF85561



- § Three chamber detergent dispenser
- § Power on/off button
- § Rotary electronic controls
- § Push-button electronic controls
- § Automatic water level



You are only using the water you really need

4 WELS star rated water efficiency means you only use the water you need

Fast wash option

Washing time adjusted according to the type of fabric and selected temperature

Starts working while you are at work or asleep

You can time your wash around your lifestyle, load your washing in the morning before work and have it ready when you return home

Options that you can really use

Pre-wash to remove heavily soiled clothes, economy option to reduce water usage, delicates and handwash wash programs

specifications

Colour	white
Inlet hose length (cm)	150
Maximum spin speed (rpm)	850
Water efficiency star rating (WELS)	4.0
Energy star rating	3.0
Product dimensions (h x w x d) mm*	850 x 600 x 540
WELS water consumption (litres)	56
Number of wash programs	11
Size (kg)	5.5
Levelling feet	2 adjustable + 2 fixed
Water supply	cold
Connection - cord length (m)	1.65
Outlet hose length (cm)	160
Drain pump filter	in drum

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

Product information

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow.

Warranty

Electrolux Home Products warrants that for domestic applications the Electrolux cooktop featured is free from defects in materials and workmanship for 2 years (3 months warranty for commercial applications). All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

Electrolux Home Products Australia

telephone: 1300 363 640
 fax: 1800 350 067
 email: customercare@electrolux.com.au
 web: www.electrolux.com.au

Electrolux Home Products New Zealand

telephone: 09 573 2230
 fax: 09 573 2221
 email: customercare@electrolux.co.nz
 web: www.electrolux.co.nz



appliancesonline
 .com.au

Australia's largest online appliance retailer