



60cm Freestanding Dishwasher

Code EMDEL15SX stainless steel

FEATURES

- 15 place setting
- Stainless steel finish
- 10 wash programs
 - Pre Wash
 - Jet Wash 18 Minutes (35°C)
 - Quick 30 Minutes (40°C)
 - Economic (50°C)
 - Super 50 Minutes (60°C)
 - Daily (60°C)
 - Dual Pro Wash (65°C)
 - Auto 1 (30°- 50°C)
 - Auto 2 (50°- 60°C)
 - Auto 3 (60°- 70°C)
- Slide out cutlery basket
- Delay start function
- Aqua stop flood protection
- Finger print resistant
- Child lock safety
- Extra Silent Function
- Half load function
- Turbo drying system
- 2 level height adjustable top basket
- Concealed heating element
- Removable top cover (30mm)
- 4.0 star energy rating
- 5.0 star water rating



15 place setting



Aqua stop flood protection hose



Slide out cutlery basket



LED Display

PRODUCT DIMENSIONS

598mm width x 850mm height x 598mm depth

WATER CONSUMPTION:

12.2 liters per wash (using economic 50 degree program)
(5.0 star water rating)

ENERGY USAGE:

245 kWh per year (Cold water connection, using economic 50 degree program seven times per week)
(4.0 star energy rating)

NOISE LEVEL: 44 dbA

INLET HOSE/DRAIN HOSE LENGTH:

1.7m / 2.1m

FILTER CLEANING INFORMATION:

Drain pump filter: requires cleaning monthly.
This will ensure no interruptions with the dishwasher operation.

WEIGHT:

52.0kg (Gross) / 50.0kg (Net)

INSTALLATION:

Please refer qualified installer to our product instruction manual.

15 PLACE SETTINGS

This dishwasher provides greater capacity in what types of dishes and cutlery can be washed.

COUNTER BALANCED DOOR

The door of this dishwasher is counter balanced, which means it can be opened to any angle thus preventing the door from bouncing and damaging any items in the dishwasher.

2 LEVEL HEIGHT ADJUSTMENT TOP BASKET

The adjustable top basket has the option of a high or low setting, allowing you to raise or lower the basket for taller dishes.

SLIDE OUT CUTLERY BASKET

Provides you, with an easy and organised way to load your cutlery.

10 WASH PROGRAMS WITH QUICK 30 MIN

10 different wash programs, from pre wash enabling you to rinse your dishes through to the intensive wash for your pots and pans. The Quick 30min cycle provides you with the full fast wash.

AQUA STOP FLOOD PROTECTION HOSE

stops the water flow when a leak or reduced pressure is detected.

AUTO WASH PROGRAMS

The auto wash programmes detect the soiled level of dishes and sets the temperature, amount of water & time required.

Dishwashers



bringing european quality to your home