

**Breville**

# Breville Urn

**Breville**

Breville is a registered trademark of Breville Holdings Pty. Limited  
ABN 98 000 092 928

## **Breville Customer Care Centre**

### **Australian Customers**

✉ Breville Customer Care Centre  
Locked Bag 2000  
Botany NSW 2019  
Australia

☎ Customer Service Ph: 1300 139 798

**Fax** (02) 9384 9601

**Email** Customer Service askus@breville.com.au

### **New Zealand Customers**

✉ Breville Customer Service Centre  
Private Bag 94411  
Greenmount  
Auckland, New Zealand

☎ Customer Service Ph: 09 271 3980

**Fax** 0800 288 513

**Email** Customer Service askus@breville.com.au



© Copyright. Breville Holdings Pty. Limited 2004  
Due to continual improvements in design or otherwise, the product you purchase may differ slightly from the one illustrated in this booklet.



PRINTED ON  
RECYCLED PAPER

Model URN6/URN10  
Issue 2/00



INSTRUCTIONS FOR USE  
MODEL URN6/URN10

## BREVILLE RECOMMENDS SAFETY FIRST

Congratulations on your purchase of a new Breville Urn. We at Breville are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer foremost in mind.

In addition, we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

### READ THESE INSTRUCTIONS BEFORE OPERATING AND SAVE FOR FUTURE REFERENCE.

This appliance is designed for the boiling of water only, never use it to heat or boil any other liquids or food.

- This appliance is for household use only. Do not use this appliance for other than its intended use. Do not use outdoors.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not leave the appliance unattended when in use.
- Do not touch hot surfaces. Use handles.

- Always use the appliance on a dry, level surface. The Urn is not intended for use on water craft or other non-stationary vehicles.
- Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.
- Do not let the cord hang over the edge of a table or counter, touch hot surfaces or become knotted.
- Do not immerse cord, plug or base in water or any other liquid.
- Always switch the appliance to off, switch the power off at the power outlet and then remove the plug when the appliance is not being used and before cleaning.
- Before use fully unwind power cord.
- If supply cord, plug or actual appliance becomes damaged in any way, return the entire appliance to the nearest authorised Breville Service Centre for examination, replacement or repair.
- Any maintenance other than cleaning should be performed at an authorised Breville Service Centre.

## KNOW YOUR BREVILLE URN

1. Capacity (Urn6 - 6 litres, Urn10 - 10 litres)
2. Stainless steel body
3. 1800 watt concealed element
4. Non-drip tap with 2 way pouring action
5. External water gauge
6. Variable heat control
7. Locking lid with ergonomic handles
8. Automatic boil dry cut out protects against overheating (safety reset button is under the base)
9. Power 'on' and 'heating' lights
10. Extra long cord with cord storage
11. Bonus drip tray
12. Steam holes (on top of lid)



## OPERATING YOUR BREVILLE URN


### BEFORE FIRST USE

It is recommended that before the first use, the Urn is filled to the maximum level, boiled and water discarded.

1. Firstly fully unwind power cord from base.
2. Place the Urn on a dry level surface and position the drip tray at the front of the Urn (tilt the Urn back and slide the drip tray under to secure in place fig 1).



3. To fill with water, turn the locking lid anti-clockwise and remove (fig 2). Use a smaller container to fill the Urn between the minimum and maximum marks. Too little water will result in the Urn switching off before the water has boiled.



**NOTE!**

Do not fill above the maximum fill line on the external water gauge as boiling water may splash out from the Urn.

4. After filling the Urn, ensure that the lid is replaced and locked into position.
5. Plug the power cord into a 230/240V power outlet and switch on. The red 'on' light will illuminate.
6. Turn the variable heat control to 'Hi' for fast boiling (fig 3). The heating light will remain on.

When the unit has boiled, select the desired setting from 'Low' to 7 to maintain temperature. The heating light will illuminate on and off maintaining the temperature selected.



7. To pour hot water, place a cup in the drip tray and push the non-drip tap down (fig 4). For continuous pouring, lift the tap in the vertical position (fig 5).

## OPERATING YOUR BREVILLE URN (CONTINUED)



Fig 4



Fig 5

8. After use, switch the appliance to off, switch the power off at the power outlet and then remove the plug when the appliance is not being used and before cleaning.



**NOTE!**

The lid should always be fitted and locked into position when in use.

Use caution when pouring water from your Urn, as boiling water will scald. Do not pour the water too quickly.

Do not open the lid when in operation as steam may escape from the top.

Steam may escape from the steam holes on top of the Urn. Exercise caution at all times.

Always empty the Urn before moving to a new position.

Never carry the Urn when in operation.

Always use the handles to carry the Urn (fig 6).



Fig 6

## SAFETY BOIL DRY PROTECTION

The Urn is fitted with a safety device which protects against overheating should the appliance be operated with insufficient water or has boiled dry. If this occurs, the Urn will stop heating. Both the red and orange lights will turn off.

Switch the appliance to off, switch the power off at the power outlet and allow the Urn to cool. Press the safety reset button under the base before refilling (fig 7). The safety device will then be reset and the Urn is ready for use.



Fig 7

## CARE AND CLEANING

Always switch the appliance to off, switch the power off at the power outlet and then remove the plug before cleaning. Never immerse the Urn controls or cord in water, or allow moisture to come in contact with these parts.

### REMOVAL OF MINERAL DEPOSITS.

Mineral deposits in tap water may cause the Urn interior to discolour. This may be removed by using a commercial kettle descaler which is available from most leading supermarkets, departments and hardware stores.

### TO CLEAN THE POLISHED EXTERIOR.

The stainless steel surface may be wiped over with a damp cloth and polished with a soft dry cloth.



**NOTE!**

Do not use chemical, steel wool, or abrasive cleaners to clean the outside of the Urn.