

# SA37X

# Smeg 34-litre microwave oven



EAN	9345025000057
size	344mmH x 560mmW x 440mmD (+33mm handle)
capacity	34 litres
turntable	345mm diameter, tempered glass
power levels	10
timer	99 minutes
power output	1000W microwave
electrical connection	suitable to plug into standard 10 amp GPO
warranty	two years parts and labour

#### 3D COOKING

The enamel interior includes two concave impressions in the rear wall and three in the left interior wall opposite the magnetron energy source in the upper right wall. These altered surfaces improve the reflective and refractive penetration of microwave energy in heating, cooking and defrosting.

#### KITCHEN TIMER

Even when the microwave oven is not being used for cooking, the minute minder, with audible beeping at the end of the selected time, has multipurpose benefits in the kitchen — eg, timing a simmer or boil on the cooktop.

### **DIGITAL CLOCK**

Time of day can be displayed in either 24-hour or 12-hour framing, and changed simply with the press of a button.

#### **DEFROST BY TIME**

When time is selected, the automatic cycle divides the thawing into periods of alternating defrosting and standing times by cycling on and off. The maximum time is 99 minutes.

## **DEFROST BY WEIGHT (AUTO DEFROST)**

Simply enter the known weight of the food to be thawed and the guesswork about the correct time is eliminated. Weights to be entered vary from 200 grams to 3000 grams.

#### **SEQUENCE PROGRAMMING**

Cook in two stages — a specific power level and duration followed by a different power level and time. Defrosting (weight or time) can also be automatically followed by one or two-stage cooking.

## **ONE-TOUCH COOKING**

Appropriate power levels and times are already preprogrammed — frozen vegetables, select 200g or 400g pasta, select one or two servings frozen pizza, select 200 or 400g

#### **DISH WARMER**

Reheat safely — without the chance of overcooking an already prepared and plated meal.

#### **AUTO COOK**

Again, appropriate power levels and times have been preprogrammed.

#### **SPEEDY COOK**

Automatic full power in 30 second increments to five minutes maximum.

# LESS, MORE

According to desired results, increase or decrease cooking or defrosting times in multiples of one minute to a maximum of 99 minutes.

### **SAFETY LOCK**

The controls can be shut down electronically to prevent unwanted access to any functions, particularly by children.



# SA37X

# Smeg 34-litre microwave oven

packaged dimensions  $630 \text{mm} \times 495 \text{mm} \times 395 \text{mm} = 0.123 \text{m}^3$ 

weight 18.5kg gross, 17kg net


oven cavity  $240 \text{mmH} \times 369 \text{mmW} \times 390 \text{mmD} = 34.54 \text{ litres}$ 


power supply 240 volt, 50 Hz


microwave consumption 1400 watt microwave output 1000 watt maximum current 5.83 amp frequency 2450 MHz power cord 1.85 metres

supplied 345mm diameter tempered glass turntable, instruction booklet for operation,

maintenance and cooking instructions







## **TRIMKITS**

60cm stainless steel trimkit, STK60X34 70cm stainless steel trimkit, STK70X34