


70cm 4 zone ceramic cooktop with knob controls, residual heat indicator and easy clean ceramic surface.



Product Details

FEATURES

Residual Heat Indicator	Easy clean ceramic surface	2.3kW powerful zone	9 power levels
-------------------------	----------------------------	---------------------	----------------

BENEFITS

Safety first

Kitchen safety comes before everything else, so our heat indicators show activated hotplates as well as hotplates that are still cooling down.

Sleek surface, easy to maintain

The ceramic glass surface wipes clean with ease. Its designed to stay looking polished with minimal effort, day after day.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Cooktop type	ceramic
Materials/Colour	black ceramic glass
Removable trim (for cleaning)	No
Knob Finish	black

CONTROLS

Controls of Cooktops	knob
Position of controls	right hand side
Indicators/display	residual heat warning lamps
Features of Cooktop	hot surface indicator

LEFT REAR ZONE

DIMENSIONS

Total product height (mm)	46
Total product width (mm)	700
Total product depth (mm)	520
Cut out width (mm)	560
Cut out depth (mm)	490

ELEMENTS/BURNERS

LEFT FRONT ZONE

Left front zone	ceramic
Left front Watts	2300
Left front number of cooking zones	1
Left front diameter mm	200

RIGHT FRONT ZONE

Left rear zone	ceramic
Left rear watts	1200
Left rear number of cooking zones	1
Left rear diameter mm	140

Right front zone	ceramic
Right front Watts	1200
Right front number of cooking zones	1
Right front diameter mm	140

RIGHT REAR ZONE

Right rear zone	ceramic
Right rear watts	1800
Right rear number of cooking zones	1
Right rear diameter mm	180

ELECTRICAL SPECIFICATIONS

Connected load KW	6.4
Type of connection	hardwired

SHIPPING

Shipping Weight (Kg)	9.5
Pack Dimensions Height (mm)	125
Pack Dimension Width (mm)	820
Pack Dimension Depth (mm)	600


STUFFING QUANTITIES

20ft	374
40ft	920
40ft HC	874

Dimensions

70cm electric cooktop

WHC742BC



IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm).
For complete installation instructions, refer to the manual provided with product.

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz