



*Thinking of you*  
**Electrolux**

EDV6051

**RRP AUS \$559.00**

6kg clothes dryer with Sensor Dry System, temperature settings, reverse tumbling action, stainless steel drum, and option to mount on wall.



# Product Details

## Features

<p><b>Sensor Dry</b> The Sensor Dry has 3 dryness level to select and it dries your clothes just right, without overdrying.</p>	<p><b>Ideal temperature settings</b> Select from Normal, Delicate and Airing to suit your different needs.</p>	<p><b>Crease Free Option</b> After the drying cycle ends, the drum automatically rotates periodically to minimise creasing.</p>	<p><b>Child safety device on door</b></p>
<p><b>Wall mount option with reversible control panel decal</b></p>	<p><b>Durable stainless steel drum</b></p>	<p><b>Delay start option</b></p>	<p><b>Efficient Reverse Tumbling Action</b> Tumble action alternates clockwise to anti-clockwise, reducing clothes tangling and bunching together, so they dry more evenly and quickly.</p>
<p><b>Clean Filter Indicator</b> A reminder to clean the filter, keeping your dryer running in optimal condition, saving time and energy.</p>			

# Product Details

## Benefits

### Sensor Dry

Sensor Dry gently and precisely dries your garments for exceptional results. This easy-to-use program will also save you precious time and energy.

### Ideal temperature settings

With a range of normal, delicate and airing settings, even your most precious items are in safe hands. The lower temperature settings ensure your delicates are dried gently and effectively.

### Efficient Reverse Tumbling Action

Tumble action alternates clockwise to anti-clockwise, reducing clothes tangling and bunching together, so they dry more evenly and quickly.

### Crease Free option

Now you can minimise creasing even when you're not there to unload your dryer. The drum rotates periodically after the drying cycle ends until you switch it off. This gives you fresh, crease-free clothing when you unload.

### Clean Filter indicator

You won't have to worry about remembering to clean your filter again. With regular cleaning, your filter will help keep your dryer running at its best. The filter is simple to clean and easily accessible when the door is opened.

# Specifications

## PRODUCT PROFILE

Domestic warranty details (yrs)	2
Dryer Type	Exhaust venting front/rear
Capacity (Kg)	6
Wall mount option	supplied with unit

## ENERGY

Energy Star Rating	2
Energy consumption (KWhr/yr)	267

## BUTTON FUNCTIONS

Reminder/ Indicators	clean lint filter reminder,child safety lock door,end of cycle,delicate,buzzer
Functions	power/on/off,program 30min,program 60min,program 90min,start/pause,normal,delicate,airing,clean filter reminder,child lock,buzzer,delay start,auto sensing,anti crease

## DIMENSIONS

Total height (mm)	795
Total width (mm)	600
Total depth (mm)	620

## CONTROLS

Type of controls	electronic push button
Options available	delicates setting,heat settings,crease free option,delay start,auto sensing,Reversible control panel,safety thermostat heater,buzzer,safety remote element
Type of display	LED
Fabric type selection	delicate,normal

## DRYING PROGRAMS

Drying Programs	auto sensing,time
Degree of dryness	extra,normal,iron dry
Venting	optional rear venting,directional front vent grille

## DRUM

Spin tub material	stainless steel
-------------------	-----------------

## DOOR

Type	See through door
Dryer Door colour	white
Door diameter	424
Door angle opening	168
Door safety	door safety switch

## CABINET

Cabinet Colour	white
Cabinet material	painted galvanized steel

## TECHNICAL

Service cord length	180
Dryer Lint filter position	front pocket
Buzzer	end of cycle
Dryer Drying time for standard load	142
Dryer Element watts	2100
Dryer Safety thermostat heater	Yes
Noise level dBA	63

## SHIPPING

Shipping Volume (m3)	0.340
Shipping Weight (Kg)	29.5
Pack Dimensions Height (mm)	830
Pack Dimension Width (mm)	630
Pack Dimension Depth (mm)	650

## STUFFING QUANTITIES

40ft HC	162
---------	-----

# Terms and Conditions

## IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

## PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

## WARRANTY

Electrolux Home Products warrants that for domestic applications the Electrolux cooktop featured is free from defects in materials and workmanship for 2 years (3 months warranty for commercial applications). All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640  
fax: 1800 350 067  
email: [customercare@electrolux.com.au](mailto:customercare@electrolux.com.au)  
web: [www.electrolux.com.au](http://www.electrolux.com.au)

### ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230  
fax: 09 573 2221  
email: [customercare@electrolux.co.nz](mailto:customercare@electrolux.co.nz)  
web: [www.electrolux.co.nz](http://www.electrolux.co.nz)