

340L frost free top mount in white finish. Featuring a full-width humidity controlled crisper, FlexStor door bin storage solutions, twist ice and serve and easy clean adjustable glass shelves.

RRP AUS \$1,049.00



Product Details

FEATURES

Full-width humidity controlled crisper bin	FlexStor™ door bin storage system	Twist ice and serve (removable) make ice with ease and cool drinks at a twist	Adjustable easy clean glass shelves
Chiller drawer	Door alarm	Reversible doors	Multi-flow air delivery system
Deodoriser Absorb pungent food smells to keep flavours fresh and distinct.	Frost free	R600a refrigerant better for the environment	Adjustable levelling feet (front)

BENEFITS

Humidity controlled crisper Offers the perfect environment for preserving fruit and vegetables, as well as having a removable crisper front for easy cleaning	Adjustable solutions with FlexStor™ As your family changes and grows, so do the requirements of your fridge. With FlexStor™ you enjoy the convenience of being able to easily change the configuration, whatever your needs. Adjust the height and position of the door bins to fit in large and smaller items and arrange your fridge your way.
Twist ice & Serve Twist ice and serve with ice caddy provides you with easy access to more ice, more often	Easy to clean with glass shelves Glass shelves improve visibility and are easy to clean

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	top mount
Exterior door finish	White
Fridge door opening	reversible (with optional door kit)
Cooling system	frost free
Refrigerant	R600a

DIMENSIONS

Total height (mm)	1645
Cabinet height (mm)	1630
Total width (mm)	598
Cabinet width (mm)	595
Total depth (mm)	650
Cabinet depth (mm)	575
Depth door open 90degree (mm)	1199
Air space above cabinet (mm)	90
Food compartment capacity (gross in litres)	250
Freezer compartment capacity (gross in litres)	89
Total Gross Capacity (L)	339

ENERGY

REFRIGERATOR SYSTEM

ENERGY

Energy Star Rating	3.5
Energy consumption (KWhr/yr)	328

FOOD COMPARTMENT

DELI-COMPARTMENT

Full width compartment	1
------------------------	---

CRISPERS

Crisper lid/shelf	glass
Crispers Runner system	floor
Full width crisper	1
Crisper features	humidity controlled

OTHER PROPERTIES

REFRIGERATOR SYSTEM

Controls	manual
Controls location	internal
Control functions	quick freeze function
Door alarm	fridge and freezer

SHELVING

Shelf material	glass
----------------	-------

LIGHTING

Main light	LED
------------	-----

FOOD COMPARTMENT DOOR

BINS

Other Properties-FOOD COMPARTMENT	Wire wine rack
-----------------------------------	----------------

Deep bottle bin	1
Shallow bin	1

FREEZER COMPARTMENT

ICE FACILITY

Twist ice and serve	2
---------------------	---

SHELVING

Shelving	glass shelf
Number of shelves	1

LIGHTING



Main light	incandescent
------------	--------------

FREEZER DOOR

INTERNAL


Freezer door bins - full width	2
--------------------------------	---

Dimensions




Recommended minimum clearances

Please note: Doors are designed to sit proud of cabinetry (not flush).



If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refrigerator increases from 30mm to 70mm (X).



When positioned in a corner, the clearance must be at least 300mm on the hinge side to allow the door to open smoothly so that bins and shelves can be removed easily.

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz