

ASSEMBLY INSTRUCTIONS

Quadro Square Desk


Size: 1000mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Tools Required: Power screwdriver; Allen key set (provided)

 2 persons required for installation

ASSEMBLY INSTRUCTIONS

Quadro Square Desk


Size: 1000mm

www.jasonl.com.au

Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



COMPONENTS

- A Table top x1
- B Legs Quadro Square x2
- C Beam x1
- D Plastic bracket x4

SCREWS

- E M8x20MM CSK x1
- F M8x20MM Socket head x1
- G M6x20MM Socket head x2
- H M6x30MM Socket head x2

- I Allen key x2

ASSEMBLY INSTRUCTIONS

Quadro Square Desk


Size: 1000mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Using Allen Key provided, attach 2 plastic brackets per leg **(D)**
(as per picture above) using M6x20MM **(G)** Socket head screw



Using Allen Key provided, attach M8x20MM Socket head **(F)**-
screw socket half way into leg for both legs **(B)**

ASSEMBLY INSTRUCTIONS

Quadro Square Desk

Size: 1000mm

www.jasonl.com.au

Need help!



Call us on
1300 527 665

jason.l
your office furniture mate



STEP 03

Adjust extendable beam **(c)** to desired length using markers and secure beam at that length using screws provided



ASSEMBLY INSTRUCTIONS

Quadro Square Desk


Size: 1000mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665


jason.l
your office furniture mate



Attach beam **(C)** to legs **(B)** using nut insert in legs
See point attached



Frame looks like this. Using Allen Key, attach beam **(C)** with Socket **(E)**



ASSEMBLY INSTRUCTIONS

Quadro Square Desk


Size: 1000mm

www.jasonl.com.au


Need help!

Call us on
1300 527 665

jason.l
your office furniture mate



Place desktop on top of frame. Nut inserts in top will align with plastic joiner brackets using M6x30MM (H) sockets attached top to frame.



(H)

TABLE TOP
BOTTOM VIEW

