



# WINE AND BEVERAGE CENTRE

# CONTENTS

02	Package Contents
02	Technical Specifications
03	Important Safety instructions
07	Assembly and parts
08	Instructions
10	Cleaning and Maintenance
10	Wiring Diagram
11	Tips
12	Troubleshooting

---

## AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

# PACKAGE CONTENTS

1 x Sheffield Wine and Beverage Cooler  
1 x Instruction Manual

Confirm all parts before disposing of the carton. Safely dispose of all plastic bags and other packaging components. They may be potentially dangerous to children.

## TECHNICAL SPECIFICATION

Model:	PLA1262DD
Rated Voltage:	220-240V~, 50Hz
Power Consumption:	0.6A
Volume:	65L
	Wine Fridge - 12 Bottle capacity
	Beverage Centre - 34 Can capacity
Climate Class:	N; SN; St; T
Min/Max Temperature:	5°C - 18°C
Working Environment:	7°C - 25°C
Max Temp Difference:	>15°C
Size (W x H x D):	510*800*450mm
Net Weight:	28.0kg

---

### AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm



## **IMPORTANT SAFETY INSTRUCTIONS**

### **READ CAREFULLY AND KEEP FOR FUTURE REFERENCE**

Carefully read this manual before using this appliance.

- Ensure that you know how the appliance functions and how to operate it.
- Maintain the appliance in accordance with the instructions to ensure that it functions properly.
- Keep this manual with the appliance. If the appliance is to be used by a third party, this instruction manual must be supplied with it.
- The safety instructions do not by themselves eliminate any danger completely and proper accident prevention measures must always be used.
- No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

Do not use this appliance if it has been dropped or damaged in any way, or if the supply cord is damaged.

#### **Intended Use**

- Indoor domestic use only: this appliance is intended for indoor domestic use only. Do not use it outdoors. Do not use it in moving vehicles or boats.
- Intended Purpose: Do not use the appliance for anything other than its intended purpose, and only use it as described in this manual
- Accessories: Do not use any accessories with the appliance that are not supplied or specifically recommended.

This appliance is intended to be used in household and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- catering and similar non-retail applications.

**WARNING:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

**WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are the type recommended by the manufacturer.

---

#### **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

Page 3

## **Supply Cord and Plug**

Always unplug from mains supply when not in use. Do not abuse or damage the power cord. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

Ensure that the socket is located near the appliance and easily accessible to quickly unplug the appliance from the mains in the event of an operating problem. Always pull out the plug from the socket (pull on the plug, not the cable)

Never bend the mains lead and never wind it around the appliance as this may lead to cable breakages. Risk of electrocution!

**WARNING:** When positioning the appliance, ensure the supply cord is not trapped or damaged.

**WARNING:** Do not locate multiple portable socket outlets or portable power supplies at the rear of the appliance.

Avoid the use of an extension cord as this may overheat and cause a risk of fire. Do not run cord under carpeting and do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area and where it will not be tripped over.

## **Earth Safety**

This appliance must be earthed. Only connect to a suitably earthed 220-240V ~ 50Hz supply socket.

## **Use and Environment**

Ensure that the appliance is placed on a flat, stable, slip-free and dry surface. Do not cover the appliance while it is operating. Ensure that there is sufficient clearance and that a safe distance to walls, ceilings and other objects are kept.

To avoid a hazard due to instability, the unit must be fixed in accordance with the instructions.

The air intake and outlet openings must never be covered or blocked. Clean the ventilation slots regularly to keep them free of dirt and prevent the openings from clogging.

Do not place any objects on the appliance.

**WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

---

## **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

Page 4

## **Supervision**

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

## **Damaged or Dropped**

Always inspect your appliance before use. Check parts are correctly attached. Do not use this appliance if it has been damaged, dropped, left outdoors or dropped in water. Return it to an authorised service dealer for examination and repair.

## **Water**

Do not immerse the appliance or its supply cord in water. Do not use with wet hands or use in damp situations. Do not use near a laundry, bath, shower or swimming pool.

If the appliance does fall into the water or get wet, first remove the plug from the mains socket before lifting the appliance out of the water! Do not turn the appliance on again until it has been checked at an approved service point. The same applies if the mains lead or appliance is damaged, or if the appliance has fallen on the floor. Risk of electrocution!

Do not operate near flammable gas or fumes.

Do not use Wine Cooler in any other orientation other than upright as shown in this manual.

## **Disposal**

**WARNING:** Risk of child entrapment.

Junked or abandoned appliances are dangerous, even if they "just sit around in the garage a few days"

- Before you throw away your wine cooler; take the door off, leaving the shelves in place so that children may not climb inside easily.
- Never allow children to operate, play with or crawl inside the appliance.

---

## **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

## **Environment-Friendly Disposal**

Old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The crossed-out Wheeled Bin symbol on the product reminds you of your obligation that when you dispose of the appliance, it must be separately collected. Contact your local authority for information concerning the correct disposal of your appliance.

**Refrigerant:** Flammable Refrigerant Gas!

**WARNING:** Do not damage the refrigerant circuit.

**DANGER** - Risk of fire or explosion. Flammable refrigerant used. DO NOT use mechanical devices to defrost the Wine cooler. DO NOT puncture refrigerant tubing.

To be repaired only by trained service personnel. Consult repair manual/owner's guide before attempting to service this product. All safety precautions must be followed.

Note: This appliance contains flammable refrigerant R600a and foaming agent cyclopentane.

CAUTION - Risk of fire or explosion due to puncturing of refrigerant tubing. Follow handling instructions carefully. Flammable refrigerant used.


---

## **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

# ASSEMBLY AND PARTS



- |                     |                  |
|---------------------|------------------|
| 1. Upper Door Hinge | 4. Shelves       |
| 2. Door Gasket      | 5. Display Shelf |
| 3. Door Handle      | 6. Bottom Hinge  |

## Before First Use

1. Remove all packaging materials and safely dispose of them.
2. Remove any stickers or labels from the appliance. (Except the rating label!).
3. Wipe the outside of the appliance with a moist cloth and dry with a towel.

## Installation and Clearance

- This appliance is designed to be free-standing only, and should not be recessed or built-in.
- Place your unit on a floor that is strong enough to support the unit when it is fully loaded. To level your unit, adjust the levelling legs at the bottom of the unit.
- The door supplied can be fitted by fully inserting supplied screws into the holes behind the gasket inside the door. The screws should be inserted all the way so they can be seen from the front of the door.
- Please the handle on the front of the door and tighten the Phillips head screw.
- Allow 10 cm of space between the top, the back and sides of the wine unit, which allows the proper air circulation to cool the compressor and condenser.

---

## AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm



- Locate the unit away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and heat sources may increase electrical consumption. Extreme cold ambient temperatures may also cause the unit not to perform properly.
- Avoid locating the unit in moist areas.
- Plug the unit into an exclusive, properly installed-grounded wall outlet. Do not under any circumstances cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician or an authorised Products service centre.
- After plugging the Wine Chiller into a wall outlet, allow the unit to cool down for 2-3 hours before placing any items in the compartment.

Remark: Please remember to keep a small amount of water in the cabinet to keep the humidity.

**WARNING! DO NOT COVER THE APPLIANCE**

**WARNING! DO NOT BUILD THE APPLIANCE INTO CABINTRY**

**NOTE:**

When you use the wine cooler for the first time or restarting the wine cooler after having been shut off for a long time, there could be a few degrees variance between the temperature you select and the one indicated on the LCD readout. This is normal and is due to the length of the activation time. Once the wine cooler is running for a few hours everything will be back to normal.

# INSTRUCTIONS

## Setting the Temperature.



- 1) Your Wine Cooler has been equipped with an "automatic" control panel lock, which will activate 20 seconds after the last time any button has been touched. Press and hold the lock key for 2 seconds to unlock.
- 2) You can turn the interior light ON or OFF by short pressing the light button. To change the temperature display between Fahrenheit and Celsius long-press the light button. The light will turn off automatically after 10 minutes.
- 3) Increase Button: Press to increase the temperature, each press raises the set temperature by 1°.

---

### AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

- 4) **Decrease Button:** Press to decrease the temperature, each press lowers the set temperature by 1°.

Minimum value: 5°C / 41°F

Maximum value: 18°C / 64°F

When the temperature measured by the temperature probe is within  $\pm 1^\circ \text{C}$  of the set temperature, the temperature display will display the set temperature value


- When you store mostly red wines, the temperature needs to be set at between 14 - 18°C (57° - 65°F).
- When you store mostly white wines, the temperature needs to be set at between 10 - 14°C (49° - 58°F).

### Storage Capacity

You can place 28 standard bottles in the PLA2800.

Many bottles may differ in size and dimensions. As such the actual number of bottles, you may be able to store may vary. Bottle capacities are approximate maximums when storing traditional Bordeaux 750ml bottles and include bulk storage.

Oversized bottles may have an impact on the number of bottles stored in the wine cooler.



### Moisture

A high build-up of moisture on the interior or exterior is not unusual during periods of high humidity. Simply wipe moisture and also minimise the times that the door is opened. Do not leave the door open longer than is necessary.

### Energy Saving Tips

- The unit should be located in the coolest area of the room, away from heat-producing appliances, and out of direct sunlight.
- Overloading the unit forces the compressor to longer.
- Be sure to wipe bottles dry before placing them in the unit. This cuts down on frost build-up inside the unit.
- The unit storage area should not be lined with aluminium foil, wax paper, or paper towelling. Liners interfere with cold air circulation, making the unit less efficient.
- Remove as many items as needed at one time, and close the door as soon as possible.

---

### AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

# ***CLEANING and MAINTENANCE***

This appliance requires little maintenance. It contains no user-serviceable parts. Any servicing requiring disassembly other than cleaning must be performed by a qualified appliance repair technician.

## **Before Cleaning**


- When not in use or before cleaning, always disconnect the appliance from the mains supply.

## **Care and Cleaning**

- Wipe the main outer body with a hot damp cloth and mild cleaning agent only, dry with a dry towel, and do not immerse this appliance in any liquid. Do not put water into the appliance.
- Wipe the inside of the appliance with a warm damp cloth.
- Wash the racks in hot soapy water, dry with a dry towel.
- Spray and wipe the door with a suitable glass cleaner.

**NOTE:** Never use rough scouring pads or abrasive cleansers on any plastic or metal parts as the surface may be damaged.

## ***Wiring Diagram***



---

## **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

# TIPS

## **Wine Storage Temperature Guide**

Important! Wine is a perishable beverage and storage conditions can impact greatly the overall taste, quality and aroma. To achieve the best possible taste wine needs to be stored and served at the right temperature.

Stored at the wrong temperature, or extremes of temperature will damage the quality of the wine. Stored at too high a temperature ages wine prematurely. Stored at too cold a temperature delays maturation and can result in deposits in the wine. The adage 'serve reds at room temperature and refrigerate whites' doesn't hold in reality. If you serve a wine too cool, the flavour will be disguised and if you serve wine too hot alcohol becomes the dominant taste.

Also important to the overall quality of the wine is fluctuations in temperatures. Wine needs to be kept at relatively constant temperatures. Serving a wine at the right temperature is a hard task as you have to take into account several elements like the presence of tannins, the structure of the wine, its age, and the style of the wine. Leftover wine in a bottle will also last longer when kept at the correct temperature.

The below table indicates suitable serving temperatures for the main varieties available. Alter to suit your taste.

15 - 18°C	Syrah, Pinot Noir, Cabernet Sauvignon, Merlot, Malbec
14 - 17°C	Pinot Noir, Cabernet Sauvignon, Merlot, Malbec
10 - 12°C	Rose wines
10 - 14°C	Chardonnay, Chenin Blanc
10 - 13°C	Riesling, Sauvignon Blanc, Pinot Gris
12°C	Long term wine storage for both whites and reds

---

## **AFTER SALES SUPPORT**

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm

# Troubleshooting

## Error codes

- EE: "EE" is displayed when the temperature probe is short-circuited or disconnected, flashes, and cooling is stopped
- LL: When the temperature measured by the temperature probe is lower than 0 degrees Celsius, "LL" is displayed, flashing, and the cooling is stopped
- HH: When the temperature measured by the temperature probe is higher than 37 degrees Celsius, "HH" is displayed, flashing, and cooling is stopped

## Forced defrosting function

When the compressor has worked for 8 hours, the compressor will stop working for 45 minutes to defrost.

### The refrigerator doesn't work



Is the power on?



Is the power supply voltage too low?

### The light is not bright



The light switch was not pressed




Is the power on?

### It's noisy



Whether the ground is flat and whether the product is placed stably



Is the product in contact with external objects or walls

### The internal temperature is not low



Improper setting temperature, please select the appropriate temperature



The door is not closed tightly or opened frequently, and the opening time is too long



Is the location exposed to direct sunlight or too close to the furnace and other heat sources



Poor heat dissipation, please check whether there is enough cooling space around the product

## AFTER SALES SUPPORT

Email: [service@prolinkbrands.co.nz](mailto:service@prolinkbrands.co.nz)

Phone: 0508 776 546 - Mon-Fri 8:30am – 4.30pm